

# Edge Intelligence

P Sushma

25MML0050

## Task 1:

- Analysing an image dataset MNIST, and applying basic processing operations.
- Applied Convolution neural network on the following dataset.
- Saving the model using pickle model.

```
[2]: import tensorflow as tf
from tensorflow.keras import layers, models
import pickle

(train_images, train_labels), (test_images, test_labels) = tf.keras.datasets.mnist.load_data()

x_train, y_train = train_images[:600], train_labels[:600]
x_test, y_test = test_images[:400], test_labels[:400]
x_train = x_train.reshape((600, 28, 28, 1)).astype('float32') / 255.0
x_test = x_test.reshape((400, 28, 28, 1)).astype('float32') / 255.0

[3]: model = models.Sequential([
    layers.Conv2D(32, (3, 3), activation='relu', input_shape=(28, 28, 1)),
    layers.MaxPooling2D((2, 2)),

    layers.Conv2D(64, (3, 3), activation='relu'),
    layers.MaxPooling2D((2, 2)),

    layers.Flatten(),
    layers.Dense(64, activation='relu'),
    layers.Dense(10, activation='softmax')
])

C:\Users\sushm\anaconda3\envs\ml_lab\lib\site-packages\keras\src\layers\convolutional\base_conv.py:113: UserWarning: Do not pass an `input_shape`/'input_dim' argument to a layer. When using Sequential models, prefer using an `Input(shape)` object as the first layer in the model instead.
super().__init__(activity_regularizer=activity_regularizer, **kwargs)

[4]: model.compile(optimizer='adam',
                  loss='sparse_categorical_crossentropy',
                  metrics=['accuracy'])

print("Training CNN on 600 images...")
model.fit(x_train, y_train, epochs=10, batch_size=32)

Training CNN on 600 images...
Epoch 1/10
19/19 — 3s 17ms/step - accuracy: 0.2834 - loss: 2.1807
Epoch 2/10
19/19 — 0s 11ms/step - accuracy: 0.6867 - loss: 1.2433
Epoch 3/10
19/19 — 0s 14ms/step - accuracy: 0.7901 - loss: 0.6412
Epoch 4/10
19/19 — 0s 20ms/step - accuracy: 0.8976 - loss: 0.3552
Epoch 5/10
19/19 — 0s 15ms/step - accuracy: 0.9333 - loss: 0.2504
Epoch 6/10
19/19 — 0s 12ms/step - accuracy: 0.9436 - loss: 0.1910
Epoch 7/10
19/19 — 0s 15ms/step - accuracy: 0.9583 - loss: 0.1598
Epoch 8/10
19/19 — 0s 14ms/step - accuracy: 0.9804 - loss: 0.0949
Epoch 9/10
19/19 — 0s 10ms/step - accuracy: 0.9836 - loss: 0.0825
Epoch 10/10
19/19 — 0s 13ms/step - accuracy: 0.9826 - loss: 0.0591
[4]: <keras.src.callbacks.history.History at 0x2b90c2adac0>

[5]: print("\nEvaluating CNN on 400 images...")
test_loss, test_acc = model.evaluate(x_test, y_test, verbose=1)
print(f"CNN Test Accuracy: {test_acc * 100:.2f}%")

Evaluating CNN on 400 images...
13/13 — 0s 12ms/step - accuracy: 0.9174 - loss: 0.2569
CNN Test Accuracy: 90.50%
```

```
[7]: with open('mnist_cnn_model.pkl', 'wb') as f:
      pickle.dump(model, f)
      print("\nCNN model saved to mnist_cnn_model.pkl")
```

CNN model saved to mnist\_cnn\_model.pkl

```
[8]: import pickle
      import os
      import tensorflow as tf
      import numpy as np
      with open('mnist_cnn_model.pkl', 'rb') as f:
          loaded_model = pickle.load(f)

      print("--- Model Loaded Successfully ---")
```

--- Model Loaded Successfully ---

```
[9]: first_layer = loaded_model.layers[0]
      weights, biases = first_layer.get_weights()

      print(f"Layer Name: {first_layer.name}")
      print(f"Weights Shape (Filter H, Filter W, Channels, Num Filters): {weights.shape}")
      print(f"Biases Shape: {biases.shape}")
      print(f"\nSample Weights (first 3x3 filter kernel):\n", weights[:, :, 0, 0])
```

Layer Name: conv2d

Weights Shape (Filter H, Filter W, Channels, Num Filters): (3, 3, 1, 32)

Biases Shape: (32,)

Sample Weights (first 3x3 filter kernel):

```
[[[-0.15950842 -0.04815693 -0.06375122]
  [-0.08455123 -0.01896419 -0.0415653 ]
  [ 0.17882669 -0.01614539  0.18866213]]
```

```
[11]: (train_images, train_labels), (test_images, test_labels) = tf.keras.datasets.mnist.load_data()
      x_train = train_images[:600].reshape((600, 28, 28, 1)).astype('float32') / 255.0
      y_train = train_labels[:600]
      x_test = test_images[:400].reshape((400, 28, 28, 1)).astype('float32') / 255.0
      y_test = test_labels[:400]
```

```
[12]: print("\n--- Resuming Training for 2 More Epochs ---")
      loaded_model.fit(x_train, y_train, epochs=2, batch_size=32)

      print("\n--- Running Evaluation ---")
      test_loss, test_acc = loaded_model.evaluate(x_test, y_test, verbose=1)
      print(f"Test Accuracy: {test_acc * 100:.2f}%")

      file_size = os.path.getsize('mnist_cnn_model.pkl') / (1024 * 1024) # Convert to MB
      print(f"\nModel File Size on Disk: {file_size:.2f} MB")
```

--- Resuming Training for 2 More Epochs ---

Epoch 1/2

19/19 — 2s 20ms/step - accuracy: 0.9830 - loss: 0.0552

Epoch 2/2

19/19 — 0s 16ms/step - accuracy: 0.9992 - loss: 0.0223

--- Running Evaluation ---

13/13 — 1s 12ms/step - accuracy: 0.9589 - loss: 0.1439

Test Accuracy: 93.50%

Model File Size on Disk: 1.43 MB

```
[13]: model.summary()
```

Model: "sequential"

Layer (type)	Output Shape	Param #
conv2d (Conv2D)	(None, 26, 26, 32)	320
max_pooling2d (MaxPooling2D)	(None, 13, 13, 32)	0
conv2d_1 (Conv2D)	(None, 11, 11, 64)	18,496
max_pooling2d_1 (MaxPooling2D)	(None, 5, 5, 64)	0
flatten (Flatten)	(None, 1600)	0
dense (Dense)	(None, 64)	102,464
dense_1 (Dense)	(None, 10)	650

Total params: 365,792 (1.40 MB)

Trainable params: 121,930 (476.29 KB)

Non-trainable params: 0 (0.00 B)

Optimizer params: 243,862 (952.59 KB)

## Task 2:

The following steps for gathering and organizing data using the Edge Impulse platform:

### 1. Account Setup

Begin by visiting the Edge Impulse website to create a new user account. Once registered and logged into the Edge Impulse Studio, you will have access to the dashboard where you can manage projects, datasets, and training configurations.

### 2. Accessing Data Acquisition

Navigate to the Data Acquisition tab within your project dashboard. This section serves as the central hub for collecting and uploading the raw inputs—such as images, audio, or sensor readings—required to train your model.

### 3. Connecting a Device

Click on the "Connect Data" option. This feature allows you to link external hardware (such as a development board, computer, or smartphone) directly to the platform for real-time data streaming.

### 4. Smartphone Integration via QR Code

Edge Impulse will generate a unique QR code on your screen. Scan this code with your smartphone to bridge your mobile device with the project. This turns your phone into a remote sensor, allowing you to capture and upload images directly to the cloud.

## 5. Labeling Data for Supervised Learning

Before capturing an image, it is vital to assign a Label (e.g., "cat," "dog," or "car"). Accurate labeling at the source ensures the machine learning model can correctly categorize the features of each image during the training process.

## 6. Dataset Partitioning (Train/Test Split)

After collecting the images, the dataset must be divided to evaluate model performance fairly. In this task, a total of 20 images were collected and split using an 80:20 ratio:

- Training Set: 16 images (used to teach the model).
- Testing Set: 4 images (used to validate accuracy).

The screenshot displays the Edge Impulse web interface for a project named 'sushma0208 / sushma0208-project-1'. The interface is divided into a left sidebar with navigation options (Dashboard, Devices, Data acquisition, Experiments, EON Tuner, Impulse design, Upgrade Plan) and a main content area. The main area has a top navigation bar with tabs: Dataset, Data explorer, Data sources, Synthetic data, AI labeling (NEW), and CSV Wizard. Below the tabs, there are two summary cards: 'DATA COLLECTED 20 items' and 'TRAIN / TEST SPLIT 80% / 20%'. To the right of these cards is a 'Collect data' section with a 'Connect a device' button. Below the summary cards is a 'Dataset' section with a table showing the collected samples. The table has columns for 'SAMPLE NAME', 'LABEL', and 'ADDED'. The samples are categorized by label: 'Chair' (3 items) and 'Keyboard' (4 items). A 'RAW DATA' section is visible on the right, with a 'Click on a sample to load...' prompt. A 'Resume tutorial' button is located at the bottom right of the interface.

SAMPLE NAME	LABEL	ADDED
Chair.6ebc1csj	Chair	Yesterday, 17:...
Chair.6ebbvr1k	Chair	Yesterday, 17:...
Chair.6ebbnf1	Chair	Yesterday, 17:...
Keyboard.6ebbrkfc	Keyboard	Yesterday, 17:...
Keyboard.6ebbrrj9	Keyboard	Yesterday, 17:...
Keyboard.6ebbrrch	Keyboard	Yesterday, 17:...
Desktop.6ebbpkip	Desktop	Yesterday, 17:...
Dataset.6ebbh2o4	Desktop	Yesterday, 17:...

EDGE IMPULSE

Dashboard

Devices

Data acquisition

Experiments

EON Tuner

Impulse design

Create impulse

Live classification

Model testing

Deployment

Upgrade Plan

Get access to higher job limits and more collaborators.

View plans

sushma0208 / sushma0208-project-1 PERSONAL

Target: Cortex-M4F 80MHz

Dataset

DATA COLLECTED 20 items

Dataset train / test split ratio

Training data is used to train your model, and testing data is used to test your model's accuracy after training. We recommend an approximate 80/20 train/test split ratio for your data for every class (or label) in your dataset, although especially large datasets may require less testing data.

SUGGESTED TRAIN / TEST SPLIT 80% / 20%

Labels in your dataset

CHAIR 80% / 20% (4 / 1)

Chair.6ebc1csj 80% / 20% (4 / 1)

Chair.6ebbvr1k 80% / 20% (4 / 1)

Chair.6ebbnvfi 80% / 20% (4 / 1)

Chair.6ebbrkfc 80% / 20% (4 / 1)

Keyboard.6ebbrej9 80% / 20% (4 / 1)

Keyboard.6ebbrach 80% / 20% (4 / 1)

Desktop.6ebbpkjp 80% / 20% (4 / 1)

Dataset.6ebbh2o4 80% / 20% (4 / 1)

Dataset.6ebbg929 80% / 20% (4 / 1)

Mouse.6ebbc286 80% / 20% (4 / 1)

Mouse.6ebb8k86 80% / 20% (4 / 1)

Mouse.6ebb8aab 80% / 20% (4 / 1)

Dismiss

Resume tutorial

EDGE IMPULSE

Dashboard

Devices

Data acquisition

Experiments

EON Tuner

Impulse design

Create impulse

Live classification

Model testing

Deployment

Upgrade Plan

Get access to higher job limits and more collaborators.


View plans

Training (16) Test (4)

SAMPLE NAME	LABEL	ADDED
Chair.6ebc1csj	Chair	Yesterday, 17:...
Chair.6ebbvr1k	Chair	Yesterday, 17:...
Chair.6ebbnvfi	Chair	Yesterday, 17:...
Keyboard.6ebbrkfc	Keyboard	Yesterday, 17:...
Keyboard.6ebbrej9	Keyboard	Yesterday, 17:...
Keyboard.6ebbrach	Keyboard	Yesterday, 17:...
Desktop.6ebbpkjp	Desktop	Yesterday, 17:...
Dataset.6ebbh2o4	Desktop	Yesterday, 17:...
Dataset.6ebbg929	Desktop	Yesterday, 17:...
Mouse.6ebbc286	Mouse	Yesterday, 17:...
Mouse.6ebb8k86	Mouse	Yesterday, 17:...
Mouse.6ebb8aab	Mouse	Yesterday, 17:...

RAW DATA

Mouse.6ebb8k86



Metadata

No metadata.

Resume tutorial